


Parallel Alignment of Nanowires for Fast Fabrication of Nanowire Based Gas Sensors



R. Jiménez-Díaz¹, J.D. Prades¹

F. Hernández-Ramírez², J. Santander³

C. Calaza³, L. Fonseca³, C. Cané³

A. Romano-Rodríguez¹

¹ MIND-IN²UB, Dept. Electrònica, Universitat de Barcelona, Spain

² IREC, Barcelona, Spain

³ Instituto de Microelectrónica de Barcelona, IMB-CNM-CSIC, Bellaterra, Spain




NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es



Previous work

Nanowires offer attractive features to improve many of the issues in solid state gas sensors




NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es



Previous work

Sensitivity




Adv. Funct. Mater. 18, 2990 (2008)

NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es




Previous work

Stability



Nanotechnol. 18, 495501 (2007)
Sens.Actuators B 144, 1 (2010)




NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es




Previous work

Response time



PCCP **11**, 7105 (2009)





NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es



Previous work

Working temperature



Sens. Actuators B **140**, 337 (2009)
PCCP, in press (2010)



NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es





Previous work

Power consumption

**“very low power consumption:
less than 20 μ W”**


(measurement AND HEATING included!!!)



APL 93, 123110 (2008)
APL 95, 053101 (2009)



NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es



MIND
Micro-nanotechnologies |
Nanoscopies per Dispositius
electrònics i fòtons

Previous work

Nanowires offer attractive features to improve
many of the issues in solid state gas sensors

Sensitivity

Stability

Response time

Working temperature

Power consumption

radius ↓

pristine surface

indiv. nanowire

UV light

indiv. nanowire

⇒ response ↑

⇒ fully reversible response

⇒ no gas diffusion

⇒ room temperature operation

⇒ self-heating effect

⇒ ultra-low power consumption

⇒ fully autonomous gas sensors

⇒ faster devices

Challenge: dealing with **nanofabrication** issues...




NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es

MIND
Micro-nanotechnologies |
Nanoscopies per Dispositius
electrònics i fòtons

Contacting & Measuring One Single Nanowire


- Dual-beam Focused-Ion Beam
- Deposit Pt-containing material (from $\text{PtC}_9\text{H}_{16}$)
 - Auger Electron Spectr.:
C (67%) + Pt (27%)
- With ions or with electrons
 - $\rho_{\text{ions}} = 100 \rho_{\text{Pt-metal}}$
 $\rho_{\text{electrons}} = 10^5 \rho_{\text{Pt-metal}}$
- Breakdown @ 10^{10} A/m^2
- Thermally stable up to 625 K

Ion-assisted deposited platinum stripe among 4 gold microelectrodes





Contacting & Measuring One Single Nanowire

Nanowires are dispersed over a substrate with pre-patterned µelectrodes




SnO_2 Nanowires

Nanotechnology 17, 5577-5583 (2006)



Contacting & Measuring One Single Nanowire




Contacting & Measuring One Single Nanowire

Electrical Characterization (2- & 4-probes)

Metal oxide NW

- Mostly non-ohmic responses
- High contact resistances
- Study of the NW requires 4p
- Self-heating at contacts




Nanotechnology 17, 5577-5583 (2006)
Physical Review B 76, 085429 (2007)

Dielectrophoretic alignment of NWs

Self-assembly technique

"When a polarizable NW is subject to a non-uniform electric field a dipole moment is induced that tends to align the nanowire in the direction of the electric field"




Proof of concept experiments

Dielectrophoretical force when applying an electrical field in a dielectric medium:

$$F_{DEP} = \frac{1}{2} \pi r^2 l \epsilon_m \text{Re}\{K\} \nabla E_{RMS}^2$$


$$\text{Re}\{K\} = \frac{\omega^2 (\epsilon_m \epsilon_p - \epsilon_m^2) + (\sigma_m \sigma_p - \sigma_m^2)}{\epsilon_m^2 \omega^2 + \sigma_m^2}$$





Dielectrophoretic alignment of NWs

Design of electrodes

Based on 2 big electrodes with sharp tips opposed.




Gaps of different lengths





Dielectrophoretic alignment of NWs

- Results on alignment of nanowires:





Dielectrophoretic alignment of NWs

- Big difference!



Dielectrophoretic alignment of NWs



2-probes configuration



- rectifying behavior
- 2 Schottky diodes
- (NW // Pt FIB).

Phys.Rev.B 76, 085429 (2007)

4-probes configuration



SnO₂-NW

$$\rho_{\text{EIB}} = 0.40 \pm 0.02 (\Omega\text{cm})^{-1}$$

$$\rho_{\text{DEP}} = 0.38 \pm 0.02 (\Omega\text{cm})^{-1}$$



NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es





Gas Sensor Measurements

Carbon monoxide

- Aligned SnO₂-NW

- Diameter: 90nm




NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es



Gas Sensor Measurements

- Comparison with non-DEP experiments:



Adv. Funct. Mater.
18, 2990 (2008)



NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es



Conclusions

- Individual NWs can be electrically contacted with the help of FIB lithography techniques
- Gas nanosensors can be fabricated using these techniques, responding to different gases (SA, N₂, CO, H₂O)
- Alignment of nanowires by dielectrophoretic techniques is feasible
- Gas nanosensors with equivalent properties as non-DEP aligned NWs can be fabricated
- This allows the increase of the throughput in gas sensor fabrication based on individual NWs



NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es



Acknowledgments

This work was partially supported by:

- European Union through projects NANOS4 and ARI (Access to Research Infrastructures)
- Spanish Ministry of Science and Technology, through the projects MAGASENS, CROMINA and NAWACS (NanoSciERA programme) and FPU grants.

This work has been developed partially using the capacities of ICTS Clean room of micro & nano fabrication of IMB-CNM (CSIC).

Thank you all for your attention!



NANOSpain, 2010 | J.D. Prades – dprades@el.ub.es

